

Configure an Eyoyo scanner for use with BrokerForce, scan these codes from top to bottom:

Set as USB HID Keyboard



P66A667

Enter Setup



P666666

Set prefix



P6FCAFF


Set tilde ~ prefix as ASC code



1



2



6

Set Suffix



P6FCAFF

Add Enter



E99311

Exit Setup



P666666